

USER INSTRUCTIONS SOCKET




USING THE SOCKET

1. UNLOCKING

2. OPEN

3. CLOSE UNTIL A CLICK



CAUTION: TO AVOID TRAPPING THE CABLE PLACE IT IN THE SLOT PROVIDED BEFORE CLOSING THE COVER

