




USING THE UNIT

1. THE HOUSING HAS TWO OPERATING POSITIONS:
- TAPS IN HOUSING
- TAPS ABOVE GROUND LEVEL IN THE EXTENDED POSITION
2. THE COVER MUST BE LOCKED OPEN IN BOTH CASES



3. PULL THE HAND GRIP UPWARDS UNTIL IT CLICKS 3 TO EXTEND THE TAPS




4. THE TAPS MUST ALWAYS BE DISINFECTED
5. FLUSH THROUGH ALL TAPS EVERY TIME BEFORE USE
6. ENSURE THAT NO WATER ENTERS THE HOUSING
7. ALWAYS CLOSE THE COVER



CRUSH HAZARD

LOCKING THE UNIT

1. CLOSE ALL TAPS AND REMOVE THE HOSES
2. UNLOCKING LEVER TO PLACE TAPS IN THE REST



3. UNLOCK THE OUTLET COVER AND REPLACE IT IN THE COVER. ENSURE THAT THIS IS LOCKED



4. REMOVE ANY FOREIGN MATTER FROM THE COVER SEAL
5. CLOSE THE COVER

